

THOR BROADCAST

User Manual



8 Program TS Matrix Hardware Transcoder

Revision 2019

A Note from Thor Broadcast about this Manual

Intended Audience

This user manual has been written to help people who have to use, integrate and to install the product. Some chapters require some prerequisite knowledge in electronics and especially in broadcast technologies and standards.

Disclaimer

No part of this document may be reproduced in any form without the written permission of Thor Broadcast.

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Thor shall have no liability for any error or damage of any kind resulting from the use of this document.

Copy Warning

This document includes some confidential information. Its usage is limited to the owners of the product that it is relevant to. It cannot be copied, modified, or translated in another language without prior written authorization from Thor Broadcast.

Table of Contents

CHAPTER 1 - INTRODUCTION	1
1.1 <i>PRODUCT OVERVIEW</i>	1
1.2 <i>KEY FEATURES</i>	1
1.4 <i>PRINCIPLE CHART & TRANSCODING</i>	3
CHAPTER 2 - INSTALLATION GUIDE	5
2.1 <i>GENERAL PRECAUTIONS.....</i>	5
2.2 <i>POWER PRECAUTIONS</i>	5
2.3 <i>DEVICE'S INSTALLATION FLOW CHART ILLUSTRATED (AS FOLLOWING)</i>	5
2.4 <i>ENVIRONMENT REQUIREMENT</i>	6
2.5 <i>GROUNDING THE UNIT.....</i>	7
CHAPTER 3 - OPERATION	8
3.1.1 <i>LCD MENU STRUCTURE</i>	9
3.1.2 <i>INITIAL STATUS.....</i>	11
3.1.3 <i>GENERAL SETTINGS FOR MAIN MENU</i>	11
3.3.1 <i>INPUT SETTING</i>	12
3.3.2 <i>OUTPUT SETTINGS</i>	13
3.3.3 <i>NETWORK SETTING</i>	17
3.3.4 <i>SAVING CONFIGURATION.....</i>	18
3.3.5 <i>LOADING CONFIGURATION.....</i>	19
3.3.6 <i>VERSION.....</i>	19
3.3.7 <i>LANGUAGE</i>	19
CHAPTER 4 - WEB NMS OPERATION.....	20
4.1 <i>LOGIN</i>	20
4.2 <i>OPERATION.....</i>	21
CHAPTER 5 - TROUBLESHOOTING	29
CHAPTER 6 - PACKING LIST	30

Chapter 1 - Introduction

1.1 Product Overview

The Thor Broadcast 8 Program HD/SD Video Transcoder is a professional bidirectional transcoder to convert video between H.264 and MPEG-2 format and also to transcode between HD and SD programs simultaneously. It is equipped with 6 ASI inputs and 8 IP inputs to receive digital channels. After transcoding, it outputs 1 MPTS & 8 SPTS through the DATA port or ASI port.

This transcoder supports advanced re-multiplexing and can effectively provide operators with real-time code rate switch and optimize the video with additional hardware features.

BISS function is now embedded to descramble ASI and IP input programs and CC function as well to transport your closed caption (or teletext).

It can be easily managed through web NMS system, and has become an ideal solution for clients to provide high quality video trans-coding in a single 1RU chassis with easy to use features.




1.2 Key features

- **8 IP (SPTS/MPTS) inputs plus 6*ASI input**
- **8 SPTS & 1 MPTS (UDP/RTP/RTSP) output; 1 ASI (MPTS) output**
- **Video Trans-coding: MPEG-2 SD/HD and H.264 SD/HD any-to-any**
- **Audio Trans-coding: LC-AAC, MP2 and AC3 any-to-any or pass-through.**
- **Maximum 8 SD or 4 HD programs trans-coding**
- **Maximum 8 channels of audio trans-coding**
- **HD and SD resolutions**
- **CBR and VBR rate control**
- **CC (closed caption)**
- **BISS descrambling**
- **IP out with null packet filtered**
- **Advanced re-multiplexing**
- **LCD & Key board local control; web NMS management**

1.3 Specifications

Stream In	MPTS/SPTS over UDP/RTP/RTSP, 1000M Base-T Ethernet Interface/ SFP interface	
	6 * ASI (BNC Type)	
BISS Descramble	Maximum 8 programs	
Video	Resolution	1920x1080I,1280x720P, 720x576i, 720x480i 480x576, 544x576, 640x576, 704x576
	Trans-coding	4*MPEG2 HD → 4*MPEG2/H.264 HD ; 4*MPEG2 HD → 4*MPEG2/H.264 SD ; 8 *MPEG2 SD → 8 *MPEG2/H.264 SD
		4* H.264 HD → 4*MPEG2/H.264 HD ; 4* H.264 HD → 4*MPEG2/H.264 SD ; 8* H.264 SD → 8 *MPEG2/H.264 SD
	Rate Control	CBR/VBR
Audio	Trans-coding	Audio Trans-coding: AAC, MP2 and AC3 any-to-any or pass-through.
	Sampling rate	48KHz
	Bit Rate	32/48/64/96/128/192/224/256/320/384Kbps
Stream Out	8*SPTS & 1*MPTS over UDP/RTP/RTSP, 1000M Base-T Ethernet Interface (UDP/RTP uni-cast / multicast) /SFP interface	
	1 ASI (as a copy of one of the 8 SPTS or the MPTS) output, BNC interface	
System Function	LCD & Key board control; web NMS management	
	Ethernet software upgrade	
General	Dimensions	430mm×405mm×45mm(WxDxH)
	Temperature range	0~45℃(Operation), -20~80℃(Storage)
	Power requirements	AC 110V±10%, 50/60Hz; AC 220V±10%,50/60Hz

1.4 Principle Chart & Transcoding



1.5 Appearance and Description

Front Panel Illustration



- | | | | |
|--------------|---|------------------------------|-------|
| 1 | 2 | 3 | 4 5 6 |
| ① LCD Screen | | ④ Power and Alarm Indicators | |
| ② NMS Port | | ⑤ TS Lock Indicators | |
| ③ Data Port | | ⑥ Lock Key | |

Rear Panel Illustration



- | | | | | | | |
|--|---|---|---|---|---|---|
| 1 | 2 | 3 | 4 | 5 | 1 | 6 |
| | | | | | | |
| 7 | 8 | | | | | |
| ① 6 ASI Inputs | | ⑤ GE Port (SFP Port); for optical signal in/out | | | | |
| ② 2 ASI Output | | ⑥ Power Switch | | | | |
| ③ Data Port for IP Signal Input/Output | | ⑦ Power Connector | | | | |
| ④ NMS Port (network management system) | | ⑧ Ground Wire Screw | | | | |

Chapter 2 - Installation Guide


2.1 General Precautions

- ✓ Must be operated and maintained in an area free of dust and debris.
- ✓ The cover should be securely fastened, do not open the cover of the chassis when the power is on.
This will also void Thor's manufacturer's warranty.
- ✓ After installation, securely stow away all loose cables, external antenna, and others.

2.2 Power precautions

- ✓ Be careful when connecting a power source to the device.
- ✓ Do not operate in wet or damp areas. Make sure the extension cable is in good condition
- ✓ Make sure the power switch is off before you start to install the device

2.3 Device's Installation Flow Chart Illustrated (as following)



2.4 Environment Requirement

Item	Requirement
Machine Hall Space	When installing unit on rack, the distance between 2 rows of machine frames should be 1.2~1.5m and the distance against wall should be no less than 0.8m.
Machine Hall Floor	Electric Isolation, Dust Free, HVAC anti-static material: $1 \times 10^7 \sim 1 \times 10^{10} \Omega$, Grounding current limiting resistance: $1 M\Omega$ (Floor bearing should be greater than 450Kg/m^2)
Environment Temperature	5~40°C(sustainable) , 0~45°C(short time) , installing air-conditioning is recommended
Relative Humidity	20%~80% sustainable 10%~90% short time
Pressure	86~105KPa
Door & Window	Installing rubber strip for sealing door-gaps and dual level glasses for window
Fire Protection	Fire alarm system and extinguisher
Power	Device power, HVAC and lighting should be independent to each other. Device power requires AC $110\text{V} \pm 10\%$, 50/60Hz or AC $220\text{V} \pm 10\%$, 50/60Hz. Please carefully check before running.

2.5 Grounding the Unit

- ✓ It is important to keep this device grounded to ensure all of the modules function correctly. Correctly grounding the device will also help prevent any electrical interference, lightening. Etc. Also it helps reject minor interference that may disrupt the devices ability to function smoothly. General rule of them, make sure the device is grounded when installing anywhere.

- ✓ Always use copper wire. When applied correctly the ground must be wrapped well to ensure maximum conduction so it can reduce any high frequencies. The copper ground wire should also be as short and thick as possible

- ✓ Installer must make sure that the two ends of the ground are well conducted and have appropriate anti-rust properties.

- ✓ It is prohibited to use any other device as part of the grounding electric circuit.

- ✓ The area of the conduction between the ground wire and device's frame should be no less than 25 m².

Chapter 3 - Operation

Keyboard Function Description:

MENU: Cancel current entered value, resume previous setting; Return to previous menu.


ENTER: Activate the parameters which need modifications, or confirm the change after modification.

LEFT/RIGHT: Choose and set the parameters.

UP/DOWN: Modify activated parameter or paging up/down when parameter is inactivated.


LOCK: Lock the screen/cancel the lock state. After pressing the lock key, the LCD will display the current configuring state.

3.1.1 LCD Menu Structure



3.3.1 Input Setting

Press UP/DOWN/LEFT/RIGHT keys to turn page or specify the target item and press ENTER key to enter into the menu of *Input Setting* when this menu is marked with ▶. It shows as bellow:




There are 4 pages displaying menus from 1.1 to 1.14 to represent the **6 ASI input channels (1.1-1.6)** and **8 IP channels (1.7-1.14)**. Enter each sub-menu to configure its parameters.

3.3.1.1 Port 1 (ASI 1 Input)

Here we take 1.1 *Port 1 (ASI)* signal input as an example to illustrate ASI inputs:

Enter 1.1 and users will find the page as shown:



P.S.: The descriptions of 1.2-1.6 Port X (ASI) are the same with 1.1 Port 1 (ASI).

3.3.1.2 Port 7 (IP Input)

Here we take *1.7 Port 7 (IP)* as an example to illustrate IP inputs:

- ▶ 1.7.1 In Protocol 1.7.2 In Address
1.7.3 IP Port 1.7.4 IGMP Snoop
- ▶ 1.7.5 Multicast

In submenus 1.7.1-1.7.5, you can configure the IP input parameters to receive the IP programs.

1.7.1 In Protocol **UDP** RTP/RTSP
 [UDP]

1.7.2 In Address
 234.001.001.001

1.7.3 IP Port
 01911

1.7.4 **IGMP Snoop** Internet Group Management Protocol Snooping
 V2 V3 [OFF]

1.7.5 Multicast
 [OFF] ON

P.S.: The descriptions of 1.8 – 1.14 Port X (IP) are the same.

3.3.2 Output Settings

This transcoder supports IP output in the form of both MPTS (Multiple Programs Transport Stream) and SPTS (Single Program Transport Stream). *Output Settings* containing 2.1- 2.9 is to configure the

MPTS and SPTS parameters and 2.10 is to configure BISS Config.

Submenus are displayed as shown below:

▶ 2.1 MPTS Output 2.3 SPTS Output 2	2.2 SPTS Output 1 2.4 SPTS Output 3
▶ 2.5 SPTS Output 4 2.7 SPTS Output 6	2.6 SPTS Output 5 2.8 SPTS Output 7
▶ 2.9 SPTS Output 8	2.10 BISS Config

3.3.2.1 MPTS Output

The processed programs can be output through one channel of MPTS (Multiple Programs Transport Stream). User can set the parameters of the MPTS under submenu 2.1.

▶ 2.1.1 MPTS Protocol 2.1.3 MPTS Port	2.1.2 MPTS IP 2.1.4 MPTS Enable
▶ 2.1.5 MPTS Filter	2.1.6 MPTS PCR Rec

Under these menus, you can set the IP protocol mode, IP address and port number for the MPTS output, and also choose enable the MPTS output or not.

2.1.1 MPTS Protocol [UDP]	UDP TRP/RTSP
2.1.2 MPTS IP 224.002.002.002	
2.1.3 MPTS Port 01001	

2.1.4 MPTS Enable
OFF [ON]

This option 'ON', it will filter output null packet.

2.1.5 MPTS Filter ON
OFF [ON]

This option 'ON'. it will recovery output PCR.

2.1.6 MPTS PCR REC ON
OFF [ON]

3.3.2.2 SPTS Output (2.2-2.9, taking 2.2 as an example)

The processed programs can also be output in the form of SPTS (Single Program Transport Stream). User can set the parameters of the SPTS under submenu 2.2-2.9. There are all together 8 channels of SPTS as this device can maximally transcode 8 programs simultaneously.

▶ 2.2.1 SPTS Protocol 2.2.2 SPTS IP
2.2.3 SPTS Port 2.2.4 SPTS Enable

▶ 2.2.5 SPTS Filter 2.2.6 SPTS PCR REC
2.2.7 SPTS PCR SEP

Under these menus, you can set the IP protocol mode, IP address and port number for the SPTS output, and also choose enable the corresponding SPTS output or not.

2.2.1 SPTS Protocol UDP
[UDP] TRP/RTSP

2.2.1 SPTS IP
224.002.002.002

2.2.2 SPTS Port
01001

2.2.3 SPTS Enable	OFF	[ON]
-------------------	-----	------

This option 'ON', it will filter output null packet.

2.2.5 SPTS Filter	OFF	ON [ON]
-------------------	-----	---------

This option 'ON', it will recovery output PCR.

2.2.6 SPTS PCR REC	OFF	ON [ON]
--------------------	-----	---------

This option 'ON', it will separate output PCR

2.2.7 SPTS PCR SEP	OFF	ON [ON]
--------------------	-----	---------

P.S.: The descriptions of 2.3-2.8 are the same with 2.2.

3.3.2.3 BISS Configuration

BISS: Basic Interoperable Scrambling System



This Transcoder also supports BISS to descramble encrypted programs from ASI or IP. Users can set the parameters of BISS under submenu 2.10.

▶ 2.10.1 Channel	2.10.2 BISS Mode
2.10.3 Select ID	2.10.4 SW Data

▶ 2.10.5 Input ID	2.10.6 ESW Data
-------------------	-----------------

➤ **BISS Channel**

Select the Channel which needs to be descrambled under this submenu.



➤ **BISS Mode/Select ID/SW Data/Input ID/ESW Data**




You need to input keys to descramble programs as per the BISS scrambling side which usually is DVB-S/S2 modulator.

The descrambling principle is as following chart:

Modulating Side (BISS SCR)	Receiving Side (BISS DESC)	Digit (0x----)
Mode 1+SW Data	Mode 1+ SW Data	12
Mode E+ESW Data + Device	Mode E + ESW Data + Device	16
Mode E+ESW Data + Input ID	Mode E + ESW Data + Input ID	16+14

3.3.3 Network Setting

You can enter *Network Setting* and modify the parameters under its corresponding submenus in the same way explained above.



Chapter 4 - WEB NMS Operation

For setting configurations you can use the front panel; also you are able to control and set the configurations on any computer by connecting the device to the web NMS Port. You should ensure that the computer's IP address is different from the Thor Transcoder.

4.1 Login

The default IP of this device is 192.168.2.136. We can modify the IP through the front panel.

Connect the pc and the device with net cable, and use ping command to confirm they are on the same network segment.

E.G. the PC IP address is 192.168.99.252, we then change the device IP to 192.168.99.xxx (xxx can be 0 to 255 except 252 to avoid IP conflict).

Use any web browser to connect the device with the PC by inputting the Encoder & Modulator's IP address in the browser's address bar and press Enter.

It will display the Login interface as Figure-1. Input the Username and Password (Both the default Username and Password are "admin".) and then click "LOGIN" to start the device setting.





Figure-1

4.2 Operation

When we confirm the login, it displays the WELCOME interface as Figure-2.



Click any item here to enter the corresponding interface to check information or set the parameters.

Transcoding output channel list which indicate the 8 programs respectively

Figure-2

Real-time output bit rate of corresponding output channel.

◆ **Input**

Click “Input” and it will display the interface as in Figure-3 where all the input programs can be modified.








Figure-3


Select one channel to view and setup the parameters of corresponding channel. For example, when we select one channel and click , it launches an interface as shown below:



CH01-CH06 ASI Channels (Read only, no need to configure)




CH07-CH14 IP Channels



: To make the current parameters shown in the web interface activate. In this way, the configuration can only be saved temporarily and system will restore the last saved configuration if the device reboots.

◆ Mux (Multiplex)

Click “Mux” and it will display the interface as Figure-4 where all the input programs can be listed, setup, and chosen to output.



ASI Input Channels & Programs:
There are 6 ASI channels in this area. Press “Parse” button to get the programs carried in each channel.

IP Input Channels & Programs:
There are 8 IP channels in this area. Press “Parse” button to get the programs carried in each channel.


Output Channels & Programs:
There are all 8 channels for output. Each channel can contain only one program.

Figure-4

PID MAP : To enable/disable the PID remapping


Click “Refresh” to refresh the input channels especially when new signal source is connected.

Click “Parse” to refresh the program list of the selected channel (ASI/IP). For example:



Parse timeout seconds Time limitation to parse the input programs


Choose one target program from any input channel and click this button to transfer it to the right box to output. You can transfer maximum 8 programs to output. Click this button to trigger a script which prompts to specify an output channel among 1-8.



Each output channel can only carry one program.

Similarly, you can cancel the multiplexed programs from the right box. Click this button to trigger a dialog box as below, where to add the PIDs which need pass through.

In some occasions, there are some PIDs which won't belong to any program, such as EPG, NIT tables and so on which user just wants to pass them through the multiplexing module without changing anything. This is the main purpose of this function.




Click “Add” to add more boxes for filling the Input & Output PIDs, then click “Save changes” to confirm.

➤ **Program Modify/Transcoding Settings/BISS Descrambling:**

: The information of multiplexed programs can be modified with this button. Click the program to be modified in the output section to trigger a dialog box as below where also to complete the audio/video out mode settings and BISS descrambling settings.

Target video format and PID can be set here:
mpeg2 video: 0x02
h.264 video: 0x1b

Source audio format and PID display:
mpeg1 audio: 0x04
mpeg2 AAC audio: 0xf
mpeg4 AAC audio: 0x11
AC3 audio: 0x06
Each output channel can carry max 8 audios out with only 1 audio can be transcoded and the other audio pass-through, or Filter



You need to input keys to descramble program according to the BISS scrambling side.

◆ **Transcoder**

Click “Transcoder” from the menu to trigger the screen as Figure-5. This interface is for setting up the format, bit rate, and PIDs of each program to be transcoded and output. Users can enter each channel (Out 01 – Out 08) to setup for each program.

Figure-5

◆ **Output**

Click “Output” from the menu to trigger the screen as Figure-6. This interface is divided into 3 parts with the first part for configuring ASI output, while the rest 2 part for configuring IP output.

ASI output: This device supports signal output through ASI ports in the form of one MPTS or one SPTS, and the stream is a mirror of the IP output stream.

IP output: This device simultaneously supports IP signal output through DATA port in the form of one MPTS and 8 SPTS. Parameters of MPTS and SPTS can be configured respectively in the second and third part in this interface.

	IP Address	Port	Protocol	Filter	PCR Se	PCR Se
MPTS	224.2.2.2	1000	SDP	OFF	OFF	OFF
SPTS 1	224.2.2.2	1001	SDP	OFF	OFF	OFF
SPTS 2	224.2.2.2	1002	SDP	OFF	OFF	OFF
SPTS 3	224.2.2.2	1003	SDP	OFF	OFF	OFF
SPTS 4	224.2.2.2	1004	SDP	OFF	OFF	OFF
SPTS 5	224.2.2.2	1005	SDP	OFF	OFF	OFF
SPTS 6	224.2.2.2	1006	SDP	OFF	OFF	OFF
SPTS 7	224.2.2.2	1007	SDP	OFF	OFF	OFF
SPTS 8	224.2.2.2	1008	SDP	OFF	OFF	OFF

Figure-6

◆ Network

Click “Network”, it will display the screen as Figure-7. Here user can change the device network configuration as needed.

NETWORK PARAMETERS					
NMS Port					
IP Address	192.168.57.246	Mask	255.255.255.000	Gateway	192.168.002.001
MAC	00-72-74-76-78-7a	Web Port	80		
DATA Port					
IP Address	192.168.001.124	Mask	255.255.255.000	Gateway	192.168.001.255
Get Set					

Figure-7

◆ Save Restore

From the menu on left side of the webpage, clicking “Save Restore”, will display the screen as Figure-8 where to save or restore your configurations

CONFIGURATIONS	
Save Configuration When you change the parameter you should save configuration, otherwise the new configuration will lost after reboot.	Save
Restore Configuration Load latest saved configuration, after click the "Restore" then please click the "Save config" button, otherwise the "Restore" parameter will lost after reboot.	Restore
Factory Set Set all configuration back to default, after click the "Factory Set" then please click the "Save config" button, otherwise the default parameter will lost after reboot.	Factory
Backup Configuration Backup current configuration to the local file, we suggest do this before set the configuration or update firmware.	Backup
Upload configuration 1. New configuration will replace the old one, please backup current configuration before load file if you use a wrong file the device may not work. 2. Please do not turn off the power while file loading, otherwise the device will not work.	浏览... 选择文件. Load File

Figure-8

Save Configuration– To save the parameters after you change it.



NOTE: New configuration will replace the old one. Please backup the current configuration before loading a file. Wrong file may cause failure of device.

Factory Set – To resume the device to factory default configuration.

Backup Configuration – To back up the device configuration to the device flash

Upload Configuration – If you need to load the backup file to restore configuration, click “Load file” to restore the latest saved configuration.

◆ Update

From the menu on left side of the webpage, clicking “Update”, it will display the screen as Figure-9 where to update firmware for the device.




Figure-9

◆ Reboot

Click “Reboot” from the menu, the screen will display as Figure-10. Click “Reboot” box and it will restart the device automatically.




Figure-10

◆ Password

When you click “Password”, it will display the password screen as Figure-11. Here you can change the Username and Password for logging into the device.

After putting the current and new Username and Password, click Apply” to save the configuration.

Status Input Mux Transcoder Output Network System

PASSWORD

Note
Modify the login name and password to make the device safely, if you forget the name and password, you can reset it by keyboard in menu 3.5. The default login name and password is "admin". Also please note the capital character and lowercase character.

Current Username admin

Current Password

New Username

New Password

Confirm New Password

Figure-11

Chapter 5 - Troubleshooting

THOR's ISO9001 quality assurance system has been approved by the CQC organization. We guarantee the products' quality, reliability and stability. All THOR products have passed all testing and manual inspections before they are shipped out. The testing and inspection scheme already covers all the Optical, Electronic and Mechanical criteria which have been published by THOR. To prevent a potential hazard, please strictly follow the operation conditions.

Prevention Measures

- Installing the device in a place where the environmental temperature is between 0 to 45 °C
- Making sure the unit has plenty of ventilation for the heat-sink on the rear panel; and other heat-sink bores if necessary
- Checking the AC input within the power supply and ensure it is working, the connection is correctly installed before switching on device
- Checking the RF output levels to stay within a tolerable range, if it is necessary
- Checking all signal cables have been properly connected
- Frequently switching on/off device is prohibited; the interval between every switching on/off must be greater than 10 seconds.

Conditions needed to unplug power cord

- Power cord or socket damage.
- Any liquid that got into the device.
- Any stuff that could cause a circuit short
- Device in damp environment
- Device has suffered from physical damage; i.e. it fell off a rack.
- Longtime idle.
- After switching on and restoring to factory setting, device still won't work properly.
- Maintenance needed on device

Chapter 6 - Packing List

Thor Transcoder HD SD 8 Programs	1 PC
ASI Cables	6PCS
Ethernet Cable	1PC
Power Cord	1PC

For Further Tech Support

1-800-521-Thor(8467)

support@thorfiber.com