# Quick configuration Guide H-1SDI-QAM-IPLL

# **NMS IP Address is 192.168.0.136**

(The PC needs to be on the same subnet with the IP address 192.168.0.XX)

# LOGIN / PASSWORD : admin/admin

#### Welcome Status Page

	Video				
atus	Video Format	Mpeg2	*		
meters	Aspect Ratio:	Auto	~	Field/Picture Encoding	: (Picture v
icoder 1	Z → Video Bitrate:	18.0	Mbps (1.0 ~ 19.5 Mbps)	Low Delay:	(Normal V)
odulator	H.264 Profile:	Main Profile	v)	H.264 Level:	Level 4
Config utput Settings	Out Resolution:	1920*1080_60)	- Auto		
em	Audio				
twork	3 - Format	AC 3	~	Dialog Normalization:	-31 (-31 ~ -1 dB)
ssword	Bitrate:	192 Kbps	~	Audio Gain:	100 (0 ~ 400%)
nfiguration					
mware te l Time	Status				
a a a a a a a a a a a a a a a a a a a	Encoder Chip Version	1.2.3.211	Input Lock:	• ←	Encoding status should be
	Input Information:	1280x720 59.94P	Bitrate:	18.768 Mbps	Enobuling status should be
	Bitrate: 0.000Mb	ips			
	20.000M				
	18.000M				
	16.000M				
	14.000M				
	12.0008				
	8.0004				
	6.000M				
	4.000M				
	2.000M				
	0.000M				

- 1. Video Format can be changed between MPEG2 or H.264
- 2. Video Bitrate should be changed to 18.0
- 3. Audio Format should be changed to AC3
- 4. Once configured click apply

### **Modulator Setup**

mary itus	Center Frequenc	cy: 68.000 MHz s): 6.0 dBm	Standard: J.83B Channel Info.(Alar	m/Active/Total): 0/4/4			
coder 1	Frequency Mode	E LIST Y	Constallation	Symbol Date	Ctature	Dit(Act/Max)	
odulator	. #	Frequency		Symbol Kate	otatus		
Config tout Settings	1						
iput Settings							
em and a second s		69 CH 4					
work							
nfiguration							
nware							
e   Time J			Channel 1 Config.		[ clo	se]	
			Standard: Level(CH Carriers):	J.83B         ✓           0.0         (-20 ~ +3 c)	<b>2</b>		
			Channel Enable: Frequency: Constellation	57 CH 2 V	<b>-</b> 3		

- 1. Press the pencil icon to bring up the pop up page to set channel modulation standard & RF level
- 2. Set modulation standard to J.83B (US Standard) or J.83A (Europe Standard)
- 3. Set required channel 2-135 from the list
- 4. Press apply

#### TS Config – is a place where you can set video strem form inputs to the desired RF outputs

welcome to use Web Mar		
THORR Z	TS Config	
Summary  Status	Output TS 1+ Stream Select General	
Parameters	⇒Nort Locked ⇒ Locked	
Encoder 1   Modulator   Ts Config   Output Settings     System   Network   Password   Configuration   Firmware   Date   Time   Log	$2 \longrightarrow \stackrel{\text{$\mathbb{B}} \to 1: \text{ Encoder 1 (prog: 1/1)}}{3} \xrightarrow{[14.7/17.1M]} & \stackrel{\text{$\mathbb{B}} \to 0 \text{ utput (prog: 1)}}{& \text{$\mathbb{C}$ A Filter}}$ $P \text{ ID Remap}$ $Refresh \text{ luput}$ $4 \longrightarrow \stackrel{\text{$\mathbb{C}===}}{& \text{$\mathbb{C}===}}$ $All \text{ luput}$ $All \text{ luput}$	
	Parse program time out: 60 seconds	

- 1. Click Output TS 1-4 it corresponds with CATV output RF 1-4
- 2. Click the plus sign to expand the encoder channel options
- 3. Check the box next to the desired source
- 4. Press the ==> button to move TS from Input to the output

#### **TS Config**

### Virtual Channel Tables Set Up

NUNDCAST 7								
mmary Status		Output TS 1+	Stream Select	General 🗲	1			
ameters	Character							
Encoder 1	Stream							
Modulator	Ch	aracter Encoding:	NORMAL	~	SDT Insert:			
TS Config	A117							
Output Settings	NIT							
stem	TIN	Insert:	Not insert	~				
Network	VCT							
Password	$2 \rightarrow vc$	T Insert:			Modulation Mode:	4	] <sup>1</sup>	
Configuration						4		
Firmware	VC	T Mode:	CVCT	~	Carrier Frequency:	500.000	(30-1000MHz)	
Date I Time								

- 1. Click the general tab
- 2. Check the VCT insert check box
- 3. Press apply

tus	Output TS				
neters	⇒Not Locked → Locked		→Normal → Overflow		
dulator Config	e ⇒1: Encoder 1 (prog: 1/1) e 1: ☑ [101] TV-101	CA Filter	B ⇒Output (prog: 1) B 1: □ TV-101 <=CH1_Encoder 1 [101]		
m			2 Program Information		
ssword nfiguration			Program From Input	CH1_Encoder 1 [101]	
nware			Service Name:	TV-101	
			SUB-CHANNEL NUMBER:	1001	
			3 → Major Channel Number:	1	
			4> Minor Channel Number:	1	
			Source Id:	1	
			Short Name:	prog1	
			Logic Channel Number:	1	
			Service Type:	0x01	
			Service Provider:	Encoder 1	
			PMT PID:	0x0020	
			PCR PID:	0x0021	
			MPEG 2 Video PID:	0v0022	

- Click Steam Select tab to go back to the previous screen
   Click the number "1" Drop box will open program information
   Change major channel number to your preference
   Change minor channel number to your preference

- 5. Click apply

### **IP Output Settings**

rs and a second s		IP Address	Port	Protocol	Pkt Length	Null PKT Filter	Program	Status	Bit(Act/Max)	
or										
Settings										
								•		
_	MPTS 4									
ration										
e										
_			Channe	l 1 Config.			[	close ]		
			2	F Pkt Null Pk	Enable:   Image: Constraint of the second	222	- - - -			

- 1. Click the pencil icon for MPTS 1 section. Drop box will open to configure channel 1
- 2. Enable and edit your IP preferences
- 3. Press apply

#### Configuration

> use Web Management		2022-12-01 14:42:37 [Exit]
	Configuration	
Summary Status	2	
Parameters		
Encoder 1     Modulator     TS Contin	When you change the parameter, you shoud save configuration ,otherwise the new configuration will lost after reboot.	
► Output Settings System	1 23ane conto 🗲 3	
Network     Password		
Configuration  Cirriware  Date Time		
► Log		

- 1. Click the configuration tab on the left hand side
- 2. Click the save tab
- 3. Press save config YOU MUST SAVE OR ALL CHANGES WILL BE LOST AFTER RESTART!