

F-4HD-TVI-TX/RX

Quick Setup Guide

Step 1: Connect Power



Connect Included Power Supplies to Transmitter (T) and Receiver (R)



“PWR” LEDs on both T and R indicate power is properly connected

Step 2: Connect Fiber

Connect Transmitter to Receiver using Single Mode Fiber (Not Included)
Distance up to 120km



“FIBER” LEDs on both T and R indicate fiber is properly connected

Step 3: Connect Video

Connect video inputs to the Transmitter and outputs to the Receiver

IMPORTANT:

Transmitter Inputs
Video 1-4 correspond
to Receiver Outputs
Video 1-4

T Video 1 = R Video 1
T Video 2 = R Video 2
T Video 3 = R Video 3
T Video 4 = R Video 4



“V1-V4” LEDs on both T and R indicate video is properly connected

Step 4: RS Data Connection

Connect Controllers to the RS port on the Receiver, and devices to be controlled to the RS port on the Transmitter



PLEASE NOTE:

F-4HD-TVI-TX/RX
Has RS485 without
return data.



“DATA” LEDs on both T and R indicate RS data is properly connected

Scan for more info:



F-4HD-TVI-TX/RX

Quick Setup Guide



<https://thorbroadcast.com>

800-521-8467

sales@thorfiber.com