

**F-4TEL-Tx/RX**

## Quick Setup Guide

**Step 1: Connect Power**

- Connect the included power supplies to the TX (Transmitter/FXS) and RX (Receiver/FXO) .
- The PWR LED will turn constant GREEN.
- The FIBER LED will blink GREEN on the TX and RX.



Connect Power



Connect Power

**Step 2: Connect Fiber**

- Connect Single mode fiber with ST/PC fiber connector
- The FIBER LED will turn constant GREEN on the TX and RX indicating optical link




Connect Fiber



Connect Fiber

**Step 3: Connect Phone Line**Connect  
Phones

(FXS 1-4)

Connect  
Lines/PBX

(FXO 1-4)



Scan for more:

