

# F-8SDI-3G-LOOP-TX/RX

## Quick Setup Guide

### Step 1: Connect Power



Connect Included Power Cables to both Transmitter (TX) and Receiver (RX)



### Step 2: Connect Fiber


Connect Transmitter to Receiver using Single Mode Fiber with ST/PC connector (Not Included) Distance up to 10km




### Step 3: Connect Inputs/Outputs

Connect SDI video inputs to the Transmitter and outputs from the Receiver and loops to the monitors

Transmitter Inputs SDI 1-8 correspond to Receiver Outputs SDI 1-8



### Step 4: Loop Outputs (Example)



V1-V8 LEDs on both TX and RX will light GREEN when INPUT is properly connected

