

F-8TEL-Tx/RX

Quick Setup Guide

Step 1: Connect Power

- Connect the included power supplies to the TX (Transmitter) and RX (Receiver) .
- The PWR LED will turn constant GREEN.
- The FIBER LED will blink GREEN on the TX and RX.



Connect Power




Connect Power

Step 2: Connect Fiber


- Connect Single mode fiber with ST/PC fiber connector
- The FIBER LED will turn constant GREEN on the TX and RX indicating optical link



Step 3: Connect Phone Line



Connect Phones (FXS 1-8)



Connect Lines (FXO 1-8)

