

**F-16A-RCA-TX/RX**

## Quick Setup Guide

**Step 1: Connect Power**

Connect the included Power Cables to the TRANSMITTER and RECEIVER.  
PWR LED will indicate when power is connected properly.

**Step 2: Connect Fiber**

Using Fiber Cable (not included) Connect the FIBER port  
of the TRANSMITTER to the FIBER port of the RECEIVER



FIBER LED on TRANSMITTER will blink and FIBER LED on RECEIVER  
will light solid when fiber connection is properly established.

### Step 3: Audio Connections (Example)



Connect Audio Inputs to TRANSMITTER using RCA cables (Not included)



Connect Audio Outputs to RECEIVER using RCA cables (Not included)



#### **IMPORTANT:**

The input channel on the TRANSMITTER will correspond to the output channel on the RECEIVER.

Tx Audio IN1 = Rx Audio Out1  
Tx Audio IN2 = Rx Audio Out2  
Tx Audio IN3 = Rx Audio Out3  
Tx Audio IN4 = Rx Audio Out4  
Tx Audio IN5 = Rx Audio Out5  
Tx Audio IN6 = Rx Audio Out6  
Tx Audio IN7 = Rx Audio Out7  
Tx Audio IN8 = Rx Audio Out8  
Tx Audio IN9 = Rx Audio Out9  
Tx Audio IN10 = Rx Audio Out10  
Tx Audio IN11 = Rx Audio Out11  
Tx Audio IN12 = Rx Audio Out12  
Tx Audio IN13 = Rx Audio Out13  
Tx Audio IN14 = Rx Audio Out14  
Tx Audio IN15 = Rx Audio Out15  
Tx Audio IN16 = Rx Audio Out16