

# F-4TEL-Tx/RX

## Quick Setup Guide

### Step 1: Connect Power

- Connect the included power supplies to the TX (Transmitter) and RX ( Receiver) .
- The PWR LED will turn constant GREEN.
- The FIBER LED will blink GREEN on the TX and RX.




Connect Power




Connect Power

### Step 2: Connect Fiber

- Connect Single mode fiber with ST/PC fiber connector
- The FIBER LED will turn constant GREEN on the TX and RX indicating optical link



Connect Fiber




Connect Fiber

### Step 3: Connect Phone Line



Connect Phones

(FXS 1-4)



Connect Lines

(FXO 1-4)

