H-8HD-EMS

Quick Setup Guide

Step 1: Connect and Login

SDI inputs 1-8

DATA NMS Connect Power

- **Connect the NMS port to your PC using an ethernet cable**
- **Open web browser and go to http://192.168.2.136**
- **Default Login/Password: admin/admin**

Step 2: Input Status

Select "Status" from the main menu

Status   Encoder   MUX   Output   ▼ System

Interface	TS Lock
Encoder 1 0.1	🟢
Encoder 2 0.1	🟢
Encoder 3 0.1	🟢
Encoder 4 0.1	🟢
Encoder 5 0.1	🟢
Encoder 6 0.1	🟢
Encoder 7 0.1	🟢
Encoder 8 0.1	🟢

TS Lock Indicators will show green when SDI inputs are properly connected

Step 3: Output settings

| Status | Encoder | MUX | Output | ▼ System |

Select "Output" from the main menu

| DATA IP Settings | MPTS Settings | SPTS Settings | ASI Output |

Then select "SPTS Settings"

IMPORTANT:
TO ACCESS STREAMS, CONNECT DEVICES TO THE DATA PORT USING AN ETHERNET CABLE

Interface	Status	Actions
Encoder 1 UDP	Output IP: 224.2.2.2 Output Port: 10002	Modify

Click "Modify" to change IP Output settings.

Repeat as needed for Encoders 2-8

Connect to the stream using the appropriate IP and Port Number
Example: udp://@224.2.2.2:10002

Step 4: Save Configuration

▼ System
Network
Save Load
Password

From the Main Menu, click "System" and "Save Load"

IMPORTANT:
YOU MUST SAVE CONFIGURATION OR CHANGES WILL BE LOST AFTER DEVICE RESTART

Save Configuration   Set
After making changes click "set" to save the new configuration

Click "Set" to save configuration

Scan for more info:

H-8HD-EMS   Quick Setup Guide