

Data Sheet: F-RFoF-6GHZ-Rx

6GHz RF over Fiber - Receiver



Analog RFoF optical Transmitter is used to convert RF signals to optical signals that can be sent and carried over long distances of fiber optic cable.

The Optical Receiver converts them back to an RF signal. The two units are connected through 1 single mode fiber up to 40Km.

RF over Fiber modules (RFoF) are commonly used in L-band, S-band satellite, radio telescopes, RF antennas distribution, broadcasting audio, and video, timing synchronization and GPS applications and other telecommunications.

It's very easy and cost effective to extend a signal from any antenna, Modulator or RF instrument, point to point or multipoint to multipoint using fiber optic splitters.

Features:

- Supper-Mini size: 31.3mm*17mm*10mm (L*W*H)
- Low power consumption
- Wide operating frequency from 10MHz to 12GHz
- Flat frequency response
- Single +5V Power supply
- Have optical power monitoring function
- Excellent EMI/EMC design
- Integrated broadband amplifier(optional)

Applications

- WiMAX / 4G / 5G
- Satellite communications
- Mobile backhaul
- GPS signal transport
- All-Digital QAM network
- Data and video distribution
- Distributed antenna system



Specifications:

Absolute Maximum Ratings

Parameter	Symbol	Condition	Min.	Max.	Unit
Operating Case Temperature	Topr		-20	+70	°C
Storage Temperature	Tstg		-40	+85	°C
DC Operating Voltage	Vd	+5V Pin	+4.7	+5.5	V
Saturation Input Optical Power	Ps	CW		10	mW
Relative Humidity	Hr			95	%
Pressure	Pr		86	106	kPa
ESD		Human body model		Class 1A	

Note: Operation beyond these absolute maximum conditions may degrade device performance, lead to device failure, shorter lifetime, and will invalidate the device warranty.

Typical Specification

Parameter	Test C	ondition	MIN.	TYP.	MAX.	Unit	
	RSC		0.01 ~	3	•		
Frequency Range	RCC		0.01 ~	6		GHz	
	RXC	RXC		0.01 ~ 12			
Optical Wavelength			800~16	550		nm	
		Tx without amplifier Rx with amplifier	-11	-3			
	RSC	Tx without amplifier Rx without amplifier	-28	-24			
		Tx without amplifier Rx with amplifier	-11	-3			
	RCC	Tx without amplifier	-30	-26			
Gain (1)	KCC	Rx without amplifier				dB	
Gain (1)	RXC	Tx without amplifier Rx without amplifier	-30	-26		u.b	
	RSC	100MHz ~ 3GHz		±1.2	±2		
	RCC	100MHz ~ 6GHz		±1.5	±2.2		
Ripple of Passband (1)(2)	RXC	100MHz ~ 12GHz		±2.0	±2.5	dB	
Input Optical Power	+25°C				10	dBm	
Back Reflection				35		dB	
DD Dognongivity	1310nı	m	0.7	0.7 0.8 mA/mI		mA/mW	
PD Responsivity	1550nı	1550nm		0.85		III/A/III W	
	RSC	100MHz ~ 3GHz		-12	-8		
RF Return loss (50 Ω)	RCC	100MHz ~ 6GHz		-10	-7	dB	
	RXC	100MHz ~ 12GHz		-10	-5	<u> </u>	
Operating Current	with a	with amplifier, RSC/RCC without amplifier, RSC/RCC/RXC		90	120	mA	
Operating Current	withou			7	10		
Operating Voltage	+5V pi	in	+4.8	+5	+5.2	VDC	

Note: (1) RSC and RCC are test with Mini optical Tx (see the below picture), RXC is test with optical Tx and the fiber is 1-meter SMF-28 fiber. (2) The ripple contains Tx and Rx.


Thor Fiber Tel: (800) 521-8467 Email: sales@thorfiber.com https://thorbroadcast.com



Connector

Type	Connector	
RF	SMA (50 Ω), Female	
Optical	FC/APC (1)	
Optical Fiber Type	SMF-28(Standard)	
Power	ewer EMI Low Pass Filter, Feed Through Capacitor	
Note (1): Other type optical connector available upon request.		

PIN Function



PIN	Name	Direction	Note
1	+5V	I	+5V DC Power
2	GND	I	GND
3	OP	О	Received Optical Power Monitor, The Voltage of OP See Below Explanation

The OP voltage (**Vop**, unit: V) VS received optical power (**Pop**, unit: mW) follow the formula:

Vop≈ D*Pop

The **D** factor defined as detection factor in V/mW unit. The typical range of **D** is from 0.25 V/mW to 0.5 V/mW. For example, **D**=0.375 V/mW, the OP voltage (**Vop**) VS received optical power (**Pop**) as shown in the table below:

Vop (V)	Pop (mW)
Vop (V) 3.75	10
3.375	9
3	8
2.625 2.25	7
2.25	6
1.875	5
•••	
0	0

The user can input the known optical power **Pop** and detect the **Vop** voltage, and then calculate the approximate value of the **D** factor of an optical receiver by the formula **Vop≈ D*Pop**. In this case, the obtained **D** factor and **Vop** can be used to estimate the optical power received by the optical receiver in practical applications.

Thor Fiber Tel: (800) 521-8467 Email: sales@thorfiber.com https://thorbroadcast.com






Heat Dissipation Requirements:

In order to ensure proper performance, heat sinking and heat removal must be provided by the user to limit maximum temperature receiver module. The bottom of the module is the preferred heat dissipation surface.

Mechanical (unit: mm)



Note: When using the module, the bottom of the module needs to be fully cooled.

Thor Fiber Tel: (800) 521-8467 Email: sales@thorfiber.com https://thorbroadcast.com

Drawing:

6GHz Mini Analog Optical Transmitter & Receiver GPS OR OR ANTENA CABLE ATSC One Single Mode Fiber from 0km to 80km



Model Selection:

F-RFoF-6GHZ-TX RFoF -RF over fiber 6Ghz optical Transmitter

F-RFoF-6GHZ-RX RFoF -RF over fiber 6Ghz optical Receiver

Thor Fiber Tel: (800) 521-8467 Email: sales@thorfiber.com https://thorbroadcast.com